

30m SOLAR PANEL KIT INSTRUCTIONS

Kit Contains: 30m x 200ml roll wire mesh 25mm x 12.5mm,
60 x Posts and Washers, Adhesive,
20 x Cable Ties & 1 x Wire Cutters.

- 1.** Thoroughly clean/dry solar panel edges to remove all traces of faecal matter and nesting debris.
- 2.** Cut the welded mesh roll into manageable sections of approximately 2 meters. Using a length of timber as a straight edge fold up the mesh approx 8-10 squares in from the outside edge. This will then sit on the roof tiles appropriately when in place.
- 3.** Place the retaining posts at 500mm intervals by sticking the PCD posts onto sides of the Solar panel and use the sealant around the post base for extra stick.
- 4.** Line up the appropriate mesh holes with the solar panel posts you installed earlier and slide the mesh over the shaft so that it protrudes through the mesh. Slide on the locking washer. Warning these are difficult to remove once in place, so ensure you are happy with the mesh panel alignment before pushing the washer home.
- 5.** Start on a corner and work your way towards the next change of direction. Cut the mesh at 45 degrees at corners. Join the corners with cable ties provided.
- 6.** Obstructions such as mounting brackets and wiring should be carefully cut around, taking care not to leave any entry points.